# Introducing Active Directory Domain Services (AD DS)

# Lab 4: Install an AD DS Domain Controller to Create a Single Domain Forest

CSCI 4417-001 Spring 2016 Jack Ramsey, Lecturer

# Install a New Windows Server 2012 Forest with the Windows Interface

#### Required Materials

This lab will require the use of the two AWS Windows Server 2012R2 instances *lastname*WindowsDC01 and *lastname*WindowsMS01 that we've already created

#### Launch Windows Server 2012 R2 instances

- 1. Launch your soon-to-be domain controller (DC) instance, *lastname*WindowsDC01 and its soon-to-be first member server, *lastname*WindowsMS01 (to complete this lab, I launched a second member server, since I'd already done it with the MS01 server. So some of the included screen shots may show -02 instead of 01
- 2. When it's ready, RDP to your Domain Controller
- 3. You may be prompted to install updates. Do so. While the updates are installing, proceed with the remaining steps in this section
- 4. The first thing we want to do is change the server's name.
- 5. You can access the appropriate dialog by right-clicking on the Metro button in the lower left corner of the display and selecting System. In the window that then displays, click on the 'Change settings' link on the right.
- 6. Name the machine *lastnamewindc01* (the length field is limited, so if you have a long last name, you may need to abbreviate it). If you get an error message about truncating the name, then you've gone past the character limit and will have to abbreviate your name. Case probably doesn't matter here I used 'RamseyWinDC01' last semester and the last lab worked fine for me. But this might be a good time to get in the habit of Linux limitations
- 7. Click on the 'Change' button.

8. Again, modify the server's domain name as you did in Step 7.




Figure 1: Changing the server's domain name, Step 9

- 9. You'll have to restart the computer for the changes to take effect. To do this (the best way), right-click on the Metro button, hover over 'Shut down or sign out', and click on <u>Shutdown</u>. Give it a reason Other (planned). Then return to the EC2 console and again shut it down from there. That's the only way you'll know for sure when to start it back up, as the dashboard won't tell you on reboots
- 10. While the server is restarting, RDP in to your member server
- 11. Rename this machine as you did the domain controller to *lastnamewinms01*, with the same length restrictions
- 12. Shut down, and then restart the member server following the steps outlined in #9

#### Install Active Directory Domain Services

- 1. Now restart your DC and RDP to it. Launch the Server Manager by clicking on the 'Server Manager' button (to the right of the Metro button). It'll take a moment to populate all of the installed roles (none, at this point)
- At the top of the display, click on '2 Add roles and features'
- 3. Click 'Next' and proceed through the Wizard. Since the operation is wizard based and fairly straightforward, I'm not going to burden you with a bunch of detailed instructions. However,
  - 1. The Role is 'Active Directory Domain Services.' You'll be prompted to add features do so

- 2. After that, accept defaults and click through to 'Finish'
- 4. After AD DS is installed, you'll notice an exclamation mark hovering by a flag icon in the upper left of the display. Click on this. There'll be a link to 'Promote this server to domain controller.' Click on that. Oddly enough, I think I mentioned this in class, Windows Server 2012 won't let you run the application, dcpromo.exe, from the command line (it used to)
- 5. This will require setting up the Domain Name Server (DNS) role. Again, it is wizard based, but you'll need some info:
  - 1. You'll be creating a new forest
  - 2. Name your root domain *lastname*.loc
  - 3. Leave the functional levels as they are ('Windows Server 2012 R2').
  - 4. Again, the DSRM password should be 'Passw0rd!'.
  - 5. On the next screen, you'll see an error message: "A delegation for this DNS server cannot be created..." Before (safely) ignoring it, consider why the alert is displayed. Hint: you're creating a Forest level DNS server
  - 6. You can click through to the end and 'Install'
- 6. Once AD DS is installed, let's add a user and make him a Domain Administrator
  - 1. In the upper right corner of the Server Manager, click on 'Tools'
  - 2. Select 'Active Directory Users and Computers'
  - 3. You may have to drill down a bit by expanding the tree on the left pane of the display, starting with your domain name
  - 4. Right-click on the 'Users' folder and select New->User




Figure 2: Adding a user

- 5. Enter 'Bob Smith' for the first and last names and 'bsmith' in the email field, then 'Next'
- 6. Enter 'Passw0rd!' for the password and uncheck 'User must change password at next logon' --



Warning! Not best practice in the RW, but ok for lab purposes

- 7. Click through to 'Finish'
- 8. Click on the 'Users' folder and select Bob
- 9. Right-click on Bob
- 10. Select Bob's Properties
- 11. Click on the 'Member Of' tab
- 12. Click the 'Add' button
- 13. Enter 'Domain' in the search box and then click the 'Check Names' button
- 14. Select 'Domain Admins' group and click 'OK'
- 15. Select the 'Domain Admins' group in the properties window and click the 'Set Primary Group' button
- 16. Then click 'OK' to leave Bob
- 17. Exit out of the AD DS Users and Computers MMC (Microsoft Management Console).

## Join your Member Server to the Domain

- 1. In order to ensure that all of the machines on your private network can communicate with one another, we need to add another rule to the inbound rules in our security group
- 2. Navigate to the security group, select the Inbound tab, and Edit
- 3. The type will be 'All traffic;' Protocol, 'All;' Port Range, 'All;' and Source, '173.1.0.0/16'
- 4. Save your changes




Figure 3: New rule for private network

- 5. RDP in to your member server instance <u>from</u> your DC01 instance, using the private IP address assigned to the MS01 instance (it should be 173.1.1.30)
- 6. Log in using Administrator and your admin password (should be Passw0rd!)
- 7. Navigate to the Network Adapter settings as you did with the domain controller (Right-click on the Metro button and select 'Network connections.' You'll only have one adapter. Right-click on it and click on 'Internet Protocol version 4 (TCP/IPv4)' and select 'Properties.')
- 8. You can leave the IP address assignment to DHCP
- 9. Enter the private IP address of your domain controller in the Preferred DNS server field (173.1.1.20). You may want to add 8.8.8.8 as a secondary DNS (anyone know what this is?)




Figure 41: Changing the DNS server

- 10. Launch PowerShell (the icon in the taskbar) of the MS01 instance
- 11. It should be running in Administrator mode. If it doesn't say 'Administrator' in the title bar, exit out, right-click on the above pictured icon, and select 'Run as Administrator' from the menu
- 12. Type in the following command:

nslookup lastname.loc

This should confirm that your member server is hitting the domain controller (it might take a minute or two)

13. Type in the following command:

add-computer -domainname *lastname*.loc -restart

Before you hit Enter, backspace the line out of existence, then type

add-com

and hit Tab. See, Tab completion also works for PowerShell! When you've typed

-domainn

\*\* Note: two "n's"

hit Tab again

Joining the domain *may* fail the first couple of times – It may take a minute or two for the member server to recognize your domain/forest. You can re-access the command by tapping the up arrow. It shouldn't though, if the nslookup command worked

- 14. You will be prompted to enter your Administrator credentials
- 15. Let's confirm that Bob is indeed a Domain Administrator
- 16. Use Bob's credentials: bsmith/Passw0rd!
- 17. If all works out, you'll be disconnected from the member server as it reboots
- 18.
- a. RDP will try to reconnect whenever a connection is severed. Just wait patiently (for me, it was around Retry #5)
- b. In lab, everyone was simply disconnected after Step 17. If this happens, wait four minutes and attempt to reconnect
- 19. When the MS01 instance prompts you for login in credentials, again use Bob's
- 20. Once you're successfully logged in, confirm that Bob is a Domain Admin by launching the Server Manger (if he doesn't have permission, it won't launch a domain user can now log in to MS01 as well, but not with administrative privileges)
- 21. Sign out of the MS01 instance by right-clicking on the Metro button, hovering over 'Shut down or sign out,' and selecting 'Sign out.' This will sign you out and close Remote Desktop
- 22. As a final confirmation of your success in creating and populating a domain, return to the Active Directory Users and Computers MMC
- 23. This time, click on Computers, on the right, instead of Users
- 24. You should see your MS01 instance listed





Figure 5: Confirming addition of instance

25. You can examine the properties of the server by right-clicking on its name in the right pane and selecting 'Properties'






Figure 6: Member server properties

26. Neat, huh?

## Ubuntu

- 1. Let's do a quick exercise with Ubuntu to wrap up today's activities
- 2. Launch your Ubuntu instance and SSH in to it
- 3. Once you are logged in, enter the following commands:

sudo wget wget http://www.webmin.com/download/deb/webmin-current.deb

(wget is a utility for downloading files directly from websites. This will download an installation package for an application called Webmin)

sudo apt-get install perl libnet-ssleay-perl openssl libauthen-pam-perl libpam-runtime libio-pty-perl apt-show-versions python (This will install necessary packages to support Webmin)

dpkg --install webmin\_1.760\_all.deb

(dpkg is the Debian package management tool. apt-get is a higher level Ubuntu tool that secretly uses dpkg to manage software. This will install the Webmin package. It takes a few minutes. You can use the -i switch instead of --install. I just used --install because it tells you at a glance what you're doing with this command.)

4. While Webmin is installing, navigate to your security groups. Add a new rule, Custom TCP Rule, TCP, 10000, 0.0.0.0/0. Webmin uses port 10000 over a secure https:// connection to connect to the instance via the web

Edit			
Туре (і)	Protocol (i)	Port Range (i)	Source (i)
HTTP	TCP	80	0.0.0.0/0
All traffic	All	All	173.1.0.0/16
SSH	TCP	22	0.0.0.0/0
Custom TCP Rule	TCP	10000	0.0.0.0/0
NS (TCP)	TCP	53	0.0.0.0/0
RDP	TCP	3389	0.0.0.0/0

Figure 7: Opening port 10000 for Webmin

- 5. Return to your Ubuntu instance
- 6. Since we're using key encryption to log in to our AWS instances, we can't use root to log in to Webmin and in real life, wouldn't want to
- 7. So, in anticipation of next week's lab, we're going to create a new user named 'webmin'

#### sudo adduser webmin

(You'll be prompted to enter a password – Passw0rd! – and confirm it. For the remaining prompts, you can simply hit Enter)

Now that we have our new 'user,' we have to elevate its privileges, so enter:

sudo usermod -a -G sudo webmin

(What this does is modify user webmin by adding it to the sudo group, granting administrative priveleges)

- 8. Now, copy the public IP address of the Ubuntu instance and launch a web browser
- 9. Before pasting the address into the address bar, enter https://
- 10. Paste the public IP address in after https://
- 11. Add ':10000' after the IP address

#### 12. Press Enter



You'll receive a dire security warning. Reassure your browser that you do indeed know what you're doing and will accept the consequences of ignoring its sage advice

- 13. After washing its hands of you and your tomfoolery, you should see a log in screen for Webmin
- 14. Enter webmin/Passw0rd!
- 15. And....viola! A web-based administrative console. I know I stress CLI skills to exhaustion, and they are important, may many administrators swear by Webmin for quick fixes. You can use it to install services, administer users, monitor resources, edit and manage files, etc. Take a minute or two to look at the various options
- 16. When you're done, log out of Webmin




Figure 8: Webmin web-based management console

## Be sure to shut down all of your instances

Your lab report is due by the beginning of class next Tuesday. It should be completed following the guidelines presented in D2L.